Temperature Controller CD101 Set-Up for Sous Vide

Display	Function	Factory Setting	Sous Vide Setting
ARU	Auto-tuning: Learns to keep temp within parameters with your setup. Must be on (1).	0	1
P	Proportional Band: percentage of leeway in temp	30	2
I	Integral Time	240	240
d	Derivative Time	60	60
Ar	Reference Value	25	25
r	Heat Reset	20	20
Pb	Adjust the temp probe offset here, after measuring water with another thermometer.	0	2.8
LCK	Data lock	0000	0011
SL1	Setting for different thermocouples. PT100 code.		1100
SL2-5			0000
SL6	Setting to heat		1
SL6-11			0
SLH	Upper temp limit you can set controller		85.0
SLL	Lower temp limit you can set controller		30.0
dH		2.0	2.0
dF		1	1
oH			0.1

CD101 PID Controller Settings for Sous Vide

For current product information, availability, and compatible options, use the verified ThermoMart links below. The preceding pages remain the original manual content.

CURRENT PRODUCT PAGE

View SVP-DTXG

All ThermoMart manuals and guides